


Play Anywhere. - Play NOW!


Warning

- Keep fingers away from hinges and joints
- To be used for restrianing Soccer Balls only
- Not a toy, do not climb on net
- Must be used with adult supervision
- Must be either Staked or Weighted down using BowBags (not supplied)
- Don't drag. To move net, use two people .



Assembly Instructions for 3'x5' and 4'x8' goals






Place double hinge on ground with net spread out away from you. Open one half (clicking sound)



3. Repeat on other half of frame. All four hinge buttons must be locked.




4. Lay the frame on the ground with the rubber feet down and the four tubes up




5. Take 2 of the four Black Poles and slot them into the 2 rear tubes.




6. Feed the 2 remaining Poles down the Nets orange 'front posts' sleeves and slot them into the front tubes.



Next take the 2 front Net loops and place over the tops of the front Poles.





9. Finally take black Loops (A) and place under Rubber Feet. (B) Stake the Net on Grass or use Bowbags on Turf (not supplied)

1 year limited Manufactures Warranty on Manufacturing defects only.
30 day money back guarantee. For a full description of WarrantyGuarantee-Terms & Conditions. See www.thebownet.com

Triad Sports Group LLC.360 Cortez Circle Camarillo, California 93012 866.950.NETS