




Warning

- To be used for Football/Soccer balls only
- Not a toy, do not climb on net
- Must be used with adult supervision

Assembly Instructions for BOWNET'S SoloKicker




1. Lay the net out, with one of the hinges on the ground, open and click long and short legs out.




2. Move to the other side of net and click out both legs. Place rubber feet on ground




3. Untangle Net and lay inbetween front legs on the ground.




4. Join the poles together (B) Then slide the pole down the long side sleeve, placing end into pipe.




5. Repeat on other side of net inserting the pole end into pipe



6. Take the two top rods and insert into couplings



7. Pull pole forward, whilst pulling Net sleeve up and loop cord over pole top. (see insert)



8. Repeat, looping with other pole. Velcro rear straps to lower frame

1 year limited Manufactures Warranty on Manufacturing defects only.
30 day money back guarantee. For a full description of Warranty-
Guarantee-Terms & Conditions. See www.thebownet.com

Triad Sports Group LLC. 360 Cortez Circle
Camarillo, California 93012 866.950.NETS